




ARMCHAIR




ARMCHAIR LEFT (or RIGHT)




ARMCHAIR without ARMRESTS




3 SEATER





3 SEATER LEFT (or RIGHT)





3 SEATER without ARMRESTS





CHAISELONGUE LEFT (or RIGHT)




CHAISELONGUE without ARMRESTS



FOOTSTOOL




CORNER 90°




DECO CUSHIONS MUST BE ORDERED SEPARATELY.


CUSHION 50x30



CUSHION 40x40




CUSHION 45x45




tea
& book

OSCAR


SET 1 LEFT (or RIGHT)
3 SEATER LEFT (or RIGHT) + ARMCHAIR RIGHT (or LEFT)




SET 2 LEFT (or RIGHT)
CHAISELONGUE LEFT (or RIGHT) + 3 SEATER RIGHT (or LEFT)




SET 3
3 SEATER LEFT + CORNER 90° + 3 SEATER RIGHT




SET 4 RIGHT (or LEFT)
3 SEATER LEFT (or RIGHT) + CORNER 90° + ARMCHAIR RIGHT (or LEFT)




SET 5 LEFT (or RIGHT)
CHAISELONGUE LEFT (or RIGHT) + 3 SEATER without ARMRESTS + CORNER 90° + ARMCHAIR RIGHT (or LEFT)



SET 6 LEFT (or RIGHT)
CHAISELONGUE LEFT (or RIGHT) + 3 SEATER without ARMRESTS + CORNER 90° + ARMCHAIR without ARMRESTS + FOOTSTOOL




SET 7 LEFT (or RIGHT)
CHAISELONGUE LEFT (or RIGHT) + 2x ARMCHAIR without ARMRESTS + CORNER 90° + ARMCHAIR without ARMRESTS + FOOTSTOOL



UPHOLSTERY **FABRIC: FC - fix cover or LC - loose cover**

FEET



COMFORT